

## Contents

Introduction . . . . .	2
Overview . . . . .	2
Storage and Stability . . . . .	2
Binding Capacity . . . . .	2
Kit Contents . . . . .	3
Materials to Be Provided by User . . . . .	3
Before Starting . . . . .	4
E.Z.N.A. SP Fungal DNA Midi Protocol For Dry Specimen . . . . .	5
E.Z.N.A. SP Fungal DNA Midi Protocol For Fresh/Frozen Specimen . . . . .	7
Troubleshooting Guide . . . . .	8

**Revised February 2004**

## Introduction

The E.Z.N.A.<sup>®</sup> SP Fungal DNA Midi Kit is specially designed for rapid and reliable isolation of high-quality total cellular DNA from Fungalspecies containing high levels of phenolic compounds and polysaccharides. Up to 500 mg of wet tissue (or 125 mg dry tissue) can be processed in less than 1 hour. The system combines the reversible nucleic acid-binding properties of the HiBind<sup>®</sup> matrix with the speed and versatility of spin column technology to eliminate polysaccharides, phenolic compounds, and enzyme inhibitors from Fungaltissue lysates. Purified DNA is suitable for PCR, restriction digestion, and hybridization techniques. There are no organic extractions, thus reducing plastic waste and hands-on time to allow multiple samples to be processed in parallel.

## Overview

If using the E.Z.N.A.<sup>®</sup> SP Fungal DNA Midi Kit for the first time, please read this booklet to become familiar with the procedures. Dry or fresh Fungaltissue is disrupted and then lysed in a specially formulated buffer containing detergent. Binding conditions are then adjusted and the sample is applied to a HiBind<sup>®</sup> DNA midi column. Two rapid wash steps remove trace contaminants such as residual polysaccharides, and pure DNA is eluted in water or low ionic strength buffer. Purified DNA can be directly used in downstream applications without the need for further purification.

## Storage and Stability

All components of the E.Z.N.A.<sup>®</sup> SP Fungal DNA Midi Kit are stable for at least 24 months from date of purchase when stored at 22°C-25°C. During shipment, or storage in cool ambient conditions, precipitates may form in Buffers SP1 and SP3. It is possible to dissolve such deposits by warming the solution at 37°C and gently shaking or stirring.

## Binding Capacity

Each HiBind<sup>™</sup> DNA Midi Column can bind up to 0.5 mg of genomic DNA. Use More than 500mg Fresh Fungal samples is not recommend.

## Kit Contents

Product Number	D5545-00	D5545-01	D5545-02
Purification Times	2 Preps	10 Preps	25 Preps
HiBind® DNA Midi Columns	2	10	25
Homogenizer Midi Columns	2	10	25
15 ml Collection Tubes*	2	10	25
Buffer SFG1	8 ml	40 ml	100 ml
Buffer SFG2	3 ml	12 ml	40 ml
Buffer SFG3	4 ml	20 ml	45 ml
SPW Buffer Concentrate	5 ml	20 ml	2 x 20 ml
Elution Buffer	3 ml	12 ml	30 ml
Instruction Booklet	1	1	1

Note : 15 ml collection tubes have been inserted with HiBind™ DNA Midi columns and Homogenizer Columns.

## Materials to be provided by user

- Centrifuge capable of at least 3,000 x g
- Nuclease-free 15 ml and 50 ml high-speed centrifuge tubes
- Waterbath equilibrated to 65°C
- Absolute (96%-100%) ethanol
- RNase A stock solution at 50 mg/ml
- Ice or Cryorack for centrifuge tubes
- (Optional for Fresh sample )Liquid nitrogen for freezing/disrupting samples

## Before Starting

- Please read the entire booklet to become familiar with the E.Z.N.A.® SP Fungal DNA Midi Kit procedures.
- Prepare an RNase stock solution at 50 mg/ml and aliquot into adequate portions. Store each aliquot at -20°C and thaw before use. Each sample will require 14 µl of this solution.
- Equilibrate Elution Buffer and Buffer SFG1 at 65°C.
- Prepare **Buffer SFG3/ethanol** stock solution as follows:

<b>D5545-00</b>	Add 8 ml absolute (96%-100%) ethanol.
<b>D5545-01</b>	Add 40ml absolute (96%-100%) ethanol to each bottle.
<b>D5545-02</b>	Add 90 ml absolute (96%-100%) ethanol to each bottle.

- Dilute SPW Buffer Concentrate with ethanol as follows and **store at room temperature**.

<b>D5545-00</b>	Add 20 ml absolute (96%-100%) ethanol.
<b>D5545-01</b>	Add 80 ml absolute (96%-100%) ethanol.
<b>D5545-02</b>	Add 80 ml absolute (96%-100%) ethanol to each bottle.

- Choose the most appropriate protocol to follow. Procedures are described for each of dried and fresh (or frozen) specimens.

<b>A. Dry Specimens</b> (Page 5)	For processing up to 125 mg powdered tissue.
<b>B. Fresh/Frozen Specimens</b> (Page 7)	For processing up to 0.5 mg fresh (or frozen) tissue.

## SP Fungal DNA Midi Protocol For Dry Specimens

Drying allows storage of field specimens for prolonged periods of time prior to processing. Samples can be dried overnight in a 45°C oven, powdered, and stored dry at room temperature. To prepare dried samples place up to 125 mg of dried tissue into a 15 ml centrifuge tube (not supplied) and grind using a pellet pestle. For critical work such as PCR and cloning, pestles are best used a single time then soaked in a dilute bleach solution immediately after use until clean. Disposable pestles may be autoclaved several times. For standard Southern analysis, the same pestle can be reused several times to grind multiple tissue samples by rinsing with ethanol and wiping the surface clean between samples. A fine powder will ensure optimal DNA extraction and yield.

- 1. To 30-125 mg powdered dry tissue add 3.5 ml Buffer.** Mix thoroughly by vortexing at maxi speed for 20 seconds. Make sure to disperse all clumps. **Note:** Make sure to disperse all tissue clumps by pipetting or vortexing. Clumped tissues will not be lysed properly and will result in lower DNA yields.
- 2. Incubate at 65°C for 30 min to 60 minutes.** Mix sample by inverting the tube several times during incubation.
- 3. Add 1 ml Buffer SFG2 and vortex to mix. Incubate the samples for 10 minutes on ice.**
- 4. Centrifuge at 3000-5000 x g for 10 min at room temperature.**  
**Note:** Some Fungal materials can generate very viscous lysates and large amounts of precipitates during this step. The preparation of a cleared lysate is essential to prevent clogging of the HiBind® DNA Midi column. For some Fungal sample samples, it is difficult to make preparation of cleared lysate by a single centrifugation step because not all particulate matter forms a compact pellet. **Omega Homogenizer Columns** can efficiently remove most cell debris and precipitates in next step; therefore they make the preparation of a cleared lysate rapid and efficient.
- 5. Carefully aspirate the supernatant to an Omega Homogenizer Midi Column, making sure not to disturb the pellet.**
- 6. Centrifuge at 3,000-5,000 x g for 5 min.** Longer centrifugation does not improve yields. The Omega Homogenizer Column will remove most precipitates and cell debris, but a small amount might pass through and form a pellet in the collection tube. Be careful not disturb this pellet in Step 7.
- 7. Carefully transfer the cleared lysate into a new 15 ml centrifuge tube; make sure not to dislodge the pellet.** Add 14ul RNase A and vortex to mix well. Incubate at room temperature for 10-30 minutes. Measure the volume of the lysate for next step.

- 8. Adjust binding conditions of the sample by adding 1.5 volume of Buffer SFG3/ethanol mixture and immediately vortex at maxi speed for 20 seconds to obtain a homogeneous mixture.** If precipitation can be seen at this point, break the precipitation by passing through a needle using a syringe or pipetting up and down 10-15 times.
- 9. Transfer 3.5 ml of the mixture (including any precipitation) to a HiBind® DNA midi column placed in a 15 ml collection tube (supplied).** Centrifuge the column at 3,000-5,000 x g for 5 min to bind DNA. Discard the flow-through liquid and re-use the collection tube for Step 10.
- 10. Repeat Step 9 by transferring the remaining of the mixture into the column, if any. Discard flow-through and reuse collection tube.**
- 11. Place the column back into the collection tube and add 3 ml SPW Buffer.** Centrifuge at 3,000-5,000 x g for 4 min and discard the flow-through liquid. Reuse the collection tube in Step 12 below.  
**NOTE:** SPW Concentrate must be diluted with absolute (96%-100%) ethanol prior to use. Follow directions on label.
- 12. Repeat wash step 11 with an additional 3 ml SPW Buffer.** Centrifuge at 3,000-5,000 x g for 3 min. Discard flow-through; reuse collection tube in Step 13.
- 13. Place the column back into 15 ml collection tube. Centrifuge empty column at 5,000 x g for 10 min to dry HiBind® Matrix.**  
*This step is **critical** for removing residual ethanol that may otherwise be eluted with DNA and interfere with downstream applications*
- 14. Transfer the column into a new 15 ml tube (not supplied). Apply 300-500 µl Elution Buffer pre-warmed to 65°C directly onto HiBind® Matrix and incubate at room temperature for 5 min.** Centrifuge at 3,000-5,000 x g for 3 min to elute DNA. Smaller volumes will significantly increase DNA concentration but result in lower yields.
- 15. Repeat Step 14 with an additional 300-500 µl of Elution buffer.** This step may be performed using another 50 ml tube to maintain a higher DNA concentration in the first eluate.  
**TIP:** To increase DNA concentration add buffer and incubate the column at 60°C-70°C for 5 min before elution. Alternatively, DNA concentration can be increased by using the first eluate for a second elution.

## SP FungalDNA Midi Protocol For Fresh/Frozen Specimens

**NOTE:** Use extreme caution when handling liquid nitrogen.

This protocol is suitable for most fresh or frozen tissue samples allowing more efficient recovery of DNA. However, due to the tremendous variation in water and polysaccharide content of plants, sample size should be limited to 500 mg. Best results are obtained with young leaves or needles.

To prepare samples collect tissue in a 15 ml mortar and freeze by dipping in liquid nitrogen with a pair of tweezers to fill the tube. Grind the tissue using a clean pestle.

- 1. Collect ground Fungal tissue (up to 500 mg) in a 15 ml centrifuge tube (not supplied) and immediately add 3 ml Buffer SFG1.** Mix thoroughly by vortexing. Make sure to disperse all clumps.

**Note:** Make sure to disperse all tissue clumps by pipetting or vortexing. Clumped tissues will not be lysed properly and will result in lower DNA yields.

- 2. Incubate at 65°C for 10 min. Mix sample few times by inverting tube during incubation.**

- 3. Add 1 ml Buffer SFG2 and vortex to mix. Incubate the samples for 10 minutes on ice. Centrifuge at 3,000-5,000 x g for 10 min at room temperature.**

**Note:** Some Fungal materials can generate very viscous lysates and large amounts of precipitates during this step. The preparation of a cleared lysate is essential to prevent clogging of the HiBind® DNA Midi column. For some Fungal sample samples, it is difficult to make preparation of cleared lysate by a single centrifugation step because not all particulate matter forms a compact pellet. **Omega Homogenizer Columns** can efficiently remove most cell debris and precipitates in next step; therefore they make the preparation of a cleared lysate rapid and efficient.

- 4. Carefully aspirate supernatant to an Omega Homogenizer Column, making sure not to disturb the pellet.**

- 5. Centrifuge at 3,000-5,000 x g for 5 min.** Longer centrifugation does not improve yields. Omega Homogenizer Column will remove most precipitates and cell debris, but a small amount might pass through and form a pellet in the collection tube. Be careful not disturb this pellet in Step 7.

- 6. Following Dry Samples Protocol Step 7-15 on page 5-6.**

## Troubleshooting Guide

Problem	Cause	Suggestions
Clogged column	Carry-over of debris.	Following precipitation with Buffer SFG2, make sure no particulate material is transferred.
	DNA pellet not completely dissolved before applying sample to column.	In Protocols A and B, ensure that DNA is dissolved in water before adding Buffer SFG3 and ethanol. This may need repeated incubation at 65°C and vortexing.
	Sample too viscous.	Do not exceed suggested amount of starting material. Alternatively, increase amounts of Buffers SFG1 and SFG2.
	Incomplete precipitation following addition of SFG2.	Increase RCF or time of centrifugation after addition of buffer SFG2.
Low DNA yield	Incomplete disruption of starting material.	For both dry and fresh samples, obtain a fine homogeneous powder before adding Buffer SFG1.
	Poor lysis of tissue.	Decrease amount of starting material or increase amount of Buffers SFG1 and SFG2.
	DNA remains bound to column.	Increase elution volume and incubate on column at 65°C for 5 min before centrifugation.
	DNA washed off.	Dilute SPW Buffer Concentrate by adding appropriate volume of absolute ethanol prior to use (Page 3).
Problems in downstream applications	Salt carry-over.	SPW Buffer must be at room temperature.
	Ethanol carry-over	Following the second wash spin, ensure that the column is dried by centrifuging 8 min at maximum speed.